

Freight instructions on open trailer disassemble Air Scoop from frame.

Step 1.
Pull the handle backwards
as shown on Fig.1 to open
the Air Scoop.



Fig. 1

Step 2.
Pull the handle
backwards and push up
in order to open the Air
Scoop.



Fig. 2



Step 3.
When the Air Scoop is open, push down on the plastic bar in the middle of the Air Scoop handle as shown on the picture below.



Fig. 3

Step 4.
Release the complete
handle from the
socket by pulling it
backwards as shown
on Fig. 4.



Fig. 4

Step. 5

Open the Air Scoop completely in order for the hinges to slide out of the sockets in each side. As shown on Fig. 6

ATTENTION!

Be careful not to scratch the vehicle.



Fig. 5



Transport instruction for Garia Golf car

THE GARIA - THE ULTIMATE EUROPEAN LUXURY GOLF CAR

Step 6.

Make sure to package and secure the Air Scoop on a place on the vehicle where it does not scratch or damage the vehicle, or where the Air Scoop can get damaged or scratched.